

**CITY OF BREMERTON  
PUBLIC WORKS AND UTILITIES**

**WATER  
STANDARD DETAILS**

**TABLE OF CONTENTS**

<b><u>GENERAL COMMENTS</u></b>	<b>5000</b>
<b>WATER METERS</b>	<b>5001-5029</b>
1" X 3/4" Domestic/Irrigation service connection	5001
1" x 1" Domestic/Irrigation service connection	5002
1 1/2" and 2" Domestic/Irrigation service connection	5003
3" to 10" compound water meter with by-pass	5005
3" to 10" Turbine Meter Installation with by-pass	5008
<b>BACKFLOW PROTECTION</b>	<b>5030-5059</b>
2 to 10 Fire Sprinkler Serv Conn	5034
Dbl Chk Valve Assy or Dbl Chk Detector Assy Below Ground	5035
Dbl Chk Valve Assy or Det. Assy RPDA RPBA Above Ground	5036
3-4 to 10 (DCVA, DCVA, RPDA) Inside	5038
3 4 to 1-1 2 Outside Double Check Valve	5039
3-4 to 1 1-2 Reduced Pressure Backflow Assembly	5040
3/4" to 2" Outside Installed Irrigation or Fire Sprinkler DCVA	5041
3/4" to 2" And smaller RPBA with Protective Cover	5042
3" to 10" (RPBA) Above Ground Installation	5043
<b>PRESSURE REDUCING VALVE ASSEMBLY (PRVA)</b>	<b>5060-5079</b>
3" to 10" Pressure Reducing Valve Station	5060
Domestic Water Service Standard PRV	5075

**FIRE HYDRANTS****5080-5085**

Fire hydrant detail	5081
Valve marker post	5082
Guard post	5083
Fire hydrant marker placement detail	5084

**VALVE OPERATION****5100-5149**

Cast iron valve box assembly	5120
------------------------------	------

**WATER MAIN BLOW-OFF AND FLUSH PROCEDURES****5200-5299**

2" blow-off assembly	5201
Typical Installation Hydro-Guard HG-4 flushing system	5205
Hydro-Guard Vertical unit HG-5 air flushing system	5210

**AIR VAC DETAILS****5300-5325**

1" air and vacuum release valve assembly	5315
2" air and vacuum release valve assembly 12" mains	5320

**PIPE LAYING DETAILS****5326-5399**

Casing installation	5330
Water main slope anchors	5331